



Installation Notes

①




Fix the solar panel on the bracket with screws

②




Pass the leading wire of the solar panel through the lamp post and lead out from the wire outlet of the support arm, and then fix the bracket on the lamp post with screws

③




Pass the leading wire of the solar panel through the arm, and fix the arm on the lamp post with screws

④



Connect the leading wire of the solar panel and the lamp

⑤



Fix the lamp on the arm with screws

Installation and use precautions

1. The solar panels must be installed in the direction of the midday sun. When installing the components, use them as lightly as possible. Do not collide or knock, so as to avoid damage.
2. There should be no tall buildings or trees in front of the solar panels to shield the sunlight, and choose to install them without shelter. The place with serious dust need do the cleaning regularly.
3. All screw terminals, etc. should be tightened according to the standard, and there should be no loose sloshing.
4. Due to different light powers and different lighting time, it needs to be set in factory. Wiring must be strictly in accordance with the corresponding wiring diagram wiring. The positive and negative poles are clearly separated, and reverse connection is strictly prohibited.
5. When repairing or replacing the light, the model and power must be the same as the original factory configuration. It is strictly forbidden to replace the light with different power models from the factory configuration or adjust the lighting time and power at will.